

Sailsense Analytics

INSTALLATION PROCEDURE

HUB with NMEA2000 interface
POD for Volvo engine with ECU

Revision history

Revision	Date	Description	Author	Checked by
A	21/06/2018	Initial release	Nicolas Z.	Jeremie S.
B	01/04/2019	Small corrections	Nicolas Z.	Yannick V.
C	25/06/2019	Minor changes	Yannick V.	Nicolas Z.
D	11/06/2020	Add user manual and safety information	Nicolas Z.	Yannick V.

BEFORE YOUR START

First of all, we would like to thank you for purchasing this product and we hope that it will bring you entire satisfaction. Before you proceed with the installation, please check for the latest version of the Installation Procedure at www.sailsense.io/first-use.

In case of question during or after installation, please reach out to our **Support teams**:

 support@sailsense.io

 +32 460 22 00 00

 Sailsense Analytics



IMPORTANT SAFETY AND WARRANTY NOTICE:



- **READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING OR OPERATING THE PRODUCT. FAILURE TO DO SO MAY CAUSE PERSONAL INJURY OR DAMAGE TO PRODUCT AND/OR PROPERTY.**
- DO NOT ATTEMPT TO INSTALL THE PRODUCT IF YOU DO NOT HAVE SUFFICIENT KNOWLEDGE OR EXPERIENCE RELATED TO INSTALLING ELECTRICAL SYSTEMS ON BOATS. MAKE SURE TO TAKE ALL THE REQUIRED SECURITY PRECAUTIONS. SWITCH-OFF THE POWER SUPPLY OF THE BOAT TO SAFELY OPERATE THE CONNECTION OR PLACEMENT OF THE DEVICE.
- Review the product package and contents prior to beginning the installation. Take care when opening the packaging and removing items. Do not operate the product if the packaging or its content are damaged or if one or more parts are missing. In case of doubt, contact Sailsense support team immediately for further assistance.
- Sailsense products can only be serviced by Sailsense or their official trained representatives. Do not attempt to open or repair the product by yourself. Failure to do so will immediately void the warranty.
- Please leave no part of the package within reach of children or irresponsible adults.
- The manufacturer and distributors of this product cannot be held liable and declines responsibility for damage or personal injury resulting from improper use or failure to observe the instructions of the Installation Procedure.

TABLE OF CONTENTS

BEFORE YOUR START	2
TABLE OF CONTENTS	3
REQUIRED MATERIAL	4
INSTALLATION OF THE HUB	7
INSTALLATION OF THE POD	12
NEED ANY HELP?	15
INSTALLATION NOTES	16
INTENDED USE OF THE PRODUCT (USER MANUAL)	17
HUB.....	17
POD.....	18
ACCESSORIES	19
NAME AND ADDRESS OF MANUFACTURER	20

REQUIRED MATERIAL

Supplied by Sailsense

FOR THE HUB

Part number	Description	Quantity	Picture
101-0001	Sailsense HUB	x1	
102-0001	Sailsense HUB Cable	x1	
704-0003	GPS Antenna	x1	
708-0001	Fuse holder	x1	
707-0001	Fuses	x5	
840-0001	Waterproof cap	x1	
828-0004	Mounting screws	x6	

FOR THE POD

Part number	Description	Quantity	Picture
101-0002	Sailsense POD	x1	
102-9999	Sailsense POD cable	x1	
920-0004	Sailsense "Y" Engine cable	x1	
840-0001	Waterproof cap	x1	
828-0004	Mounting screws	x6	

Not supplied by Sailsense

- Silicone to glue the antenna
- Cleaning tissues
- Cable ties & cable ties mounts
- NMEA2000 cable adapter for Raymarine or Simrad NMEA backbones
- Additional wire to connect the batteries or gauges
- Crimps and vamp clamps

INSTALLATION OF THE HUB


STEP 1: IDENTIFY THE BEST PLACE TO INSTALL THE HUB

The HUB should be installed **inside** the boat.

In order to minimize the installation time and to limit the need for dragging additional wires, the HUB should be located as close as possible from:


- a NMEA2000 T-connector
- a 12-24V DC power source (optional)
- the gauges you wish to monitor (optional)

Note: the ideal place for most monohulls is behind the electrical panel.



STEP 2: CONNECT THE HUB CABLE TO THE NMEA2000 DATA SOURCE

Find a free entry on the NMEA2000 backbone of the boat and plug the NMEA2000 connector of the Sailsense HUB Cable.



For Raymarine or Simrad NMEA2000 backbones, you may need an adaptor cable (not provided by Sailsense).

STEP 3: CONNECT THE HUB CABLE TO A SECONDARY POWER SOURCE (OPTIONAL)

By default, the HUB is powered through the NMEA2000 cable. It is ON when the navigation instruments are switched-on at the electrical panel.

For enhanced experience, we recommend to also connect the HUB to the 12V-24V power source of the boat. You can either connect the HUB before or after the main switch of the boat. In the first case, the HUB will always be ON. In the latter, it will be ON whenever the main switch is ON.


[!] Do not perform this step, if you do not have experience with installing electrical systems on boats. Make sure to take all the required security measures when working with electrical systems.

[!] Sailsense HUB works with 12-30 V DC power inputs.


To add a secondary power source, drag a wire (not provided by Sailsense) between the (+) of the boat batteries or of the electrical panel and plug it on the **left side** of the fuse holder.

Drag a wire (not provided by Sailsense) between the (-) or ground of the boat batteries or of the electrical panel and plug it on the **left side** of the fuse holder.

Prepare the fuse holder



Connect to the 12-24V main switch



Connect the Sailsense HUB Cable to the **right side** of the fuse holder with the following color coding.

BATTERY WIRE	SAILSENSE CABLE
(+) of the batteries / DC power source	Red or Orange wire
(-) of the batteries / DC power source	Black or Grey wire

Overall set-up

To the 12-24V power source



STEP 4: CONNECT THE CABLE TO GAUGES (OPTIONAL)

You can skip this step if you do not want to monitor gauges data with the HUB.


With a voltmeter, identify the wire at the back of your gauge that sends the tank level data.

Crimp a vamp clamp to that wire. Drag a wire (not provided by Sailsense) between the vamp clamp and any available plug on the **left side** of the fuse holder provided by Sailsense.

Connect the Sailsense HUB Cable to the **right side** of the fuse holder with the following color coding:

TANK WIRE	SAILSENSE CABLE
Tank 1	Green wire
Tank 2	Blue wire
Tank 3	White wire

Overall set-up



STEP 5: SCREW THE FUSE HOLDER

You can ignore this step if you have not performed step 3 or 4.

If you have used the fuse holder as required in steps 3 or 4, screw the fuse holder to the boat.

STEP 6: SCREW THE HUB TO THE BOAT

Place the waterproof cap on the ethernet connector.



Screw the hub to the boat, with its **connectors facing down**.



We recommend installing the HUB

- at least 1m above the water level
- at least 0.5m away from other metallic objects or from the water or fuel tanks


THIS SIDE UP



STEP 7: CONNECT THE GPS ANTENNA

<p>Glue the GPS antenna horizontally on a flat and clean surface (with silicon).</p> <p>The antenna should be placed inside the boat, as close as possible to the deck with its largest black surface pointing to the sky.</p>	
<p>Screw the antenna to the HUB</p>	

STEP 8: PLUG THE CABLE TO THE HUB

<p>Plug the cable to the hub.</p>	
<p>After about 15 seconds, the logo will become white.</p> <p>After about 2 minutes, the logo will become blue.</p> <p>Your device should be visible in the Sailsense Fleet Management Platform within 5 minutes.</p>	

INSTALLATION OF THE POD

STEP 1: IDENTIFY THE BEST PLACE TO INSTALL THE POD

The POD should be installed **inside** the boat.

The best place to install the POD is under the bed of the aft cabin, close to the engine room.



STEP 2: CONNECT SAILSENSE “Y” ENGINE CABLE TO THE ENGINE

From the aft cabin, open the engine compartment panel to access the side of the engine.


Locate the engine ECU on the side of the engine.

Unplug the Multilink cable from the ECU. The Multilink cable is the 6 pin connector that is the closest to the engine.

Plug the Sailsense Y Engine Cable to the ECU, where the Multilink cable was previously connected.


Plug the Multilink cable to the other end of the Sailsense Y Engine Cable.

Plug the Sailsense POD Cable to the loose end of the Sailsense Y Engine Cable.



STEP 3: DRAG THE 'LOOSE END' OF THE POD CABLE TO THE COMPARTMENT UNDER THE BED

Drag the loose end of the Sailsense POD Cable (see previous step) to any compartment under the bed where you have enough room to install the POD.



STEP 4: SCREW THE POD TO THE BOAT

Place the waterproof cap on the ethernet connector.




Screw the POD to the boat, with its **connectors facing down**.

We recommend installing the POD

- at least 0.5m away from other metallic objects or from the water or fuel tanks



STEP 5: PLUG THE CABLE TO THE POD

<p>Plug the cable to the POD.</p>	
<p>Turn on the engine.</p> <p>After about 15 seconds, the logo of the POD will become white.</p> <p>After about 2 minutes, the logo will become blue.</p> <p>Your device should be visible in the Sailsense Fleet Management Platform within 5 minutes.</p>	

NEED ANY HELP?

For any assistance, please contact support@sailsense.io

INSTALLATION NOTES

Date		Boat Name		
Client		Type of boat		
Installed by		Engine(s) type		
Engine1 hours		Engine2 hours		
	SERIAL	Location	Interface type	Led Color
HUB				
POD 1 (if applies)				
POD 2 (if applies)				
POD 3 (if applies)				
POD 4 (if applies)				

INTENDED USE OF THE PRODUCT (USER MANUAL)

HUB

The HUB is used to monitor and gather data from the main electrical systems aboard of leisure crafts. It can be interfaced with any NMEA2000® equipment, NMEA0183® equipment, J1939® engines, as well as analog systems such as batteries, gauges, switches, ... It can also record the GPS position of the boat.

The HUB serves as gateway between the boat systems and Sailsense' servers hosted in the cloud (through GSM network) as well as between Sailsense PODs (optional) and Sailsense' servers.

Technical specifications ¹

Model	HUB01
Use	Inside leisure boat
Altitude	up to 2000 m
Temperature range & Humidity	+5 °C to +40 °C 5-80 %RH related to voltage range with no condensation.
Storage temperature & storage relative humidity	-40 °C to +70 °C 5 to 80 % (no condensation)
Dimensions	149 / 129 / 44 mm
Input voltage & consumption	12V – 28V $\overline{\text{---}}$ (DC) 4,6 Wmax
Number of Analog inputs	3
Analog inputs measures	0-30V $\overline{\text{---}}$ (DC)
Number of CAN inputs	1
Box material	PC ABS V0
PCB material	FR4 UL94
Inner fuse protection	32V $\overline{\text{---}}$ (DC) 3A Fast blow
SuperCap	5VDC $\overline{\text{---}}$ - 40 °C - + 65 °C

¹ Sailsense Analytics SA/NV reserves the right to alter the characteristics of the products anytime.

POD

The POD is used to monitor and gather data from the main electrical systems aboard of leisure crafts. It can be interfaced with any NMEA2000® equipment, NMEA0183® equipment, J1939® engines, as well as analog systems such as batteries, gauges, switches, ...

The POD connects to Sailsense' servers hosted in the cloud (through WIFI network) through a Sailsense HUB.

Technical specifications ²

Model	POD01
Use	Inside leisure boat
Altitude	up to 2000 m
Temperature range & Humidity	+5 °C to +40 °C 5-80 %RH related to voltage range with no condensation.
Storage temperature & storage relative humidity	-40 °C to +70 °C 5 to 80 % (no condensation)
Dimensions	130 / 100 / 44 mm
Input voltage & consumption	12V – 28V $\overline{\text{---}}$ (DC) 2,1 Wmax
Number of Analog inputs	3
Analog inputs measures	0-30V $\overline{\text{---}}$ (DC)
Number of CAN inputs	1
Box material	PC ABS V0
PCB material	FR4 UL94
Inner fuse protection	32V $\overline{\text{---}}$ (DC) 3A Fast blow
SuperCap	5VDC $\overline{\text{---}}$ - 40 °C - + 65 °C


² Sailsense Analytics SA/NV reserves the right to alter the characteristics of the products anytime.

ACCESSORIES ³

Cable

Specifications: UL 2904 with colors and tinned wires. Cable sheath resistant to oil and chemicals. Reference of the main circular connector: DD-18BFFA-LL7001

Color and pinout table:

Connector	PIN	
DD-18BFFA-LL7001	2	
DD-18BFFA-LL7001	4	
DD-18BFFA-LL7001	3	
DD-18BFFA-LL7001	5	
DD-18BFFA-LL7001	10	
DD-18BFFA-LL7001	12	
DD-18BFFA-LL7001	9	
DD-18BFFA-LL7001	1	
DD-18BFFA-LL7001	11	
DD-18BFFA-LL7001	13	
DD-18BFFA-LL7001	7	
DD-18BFFA-LL7001	N/A	

Fuse box

Specifications: fuse holder characteristics with automotive 3A fuses (ref:0287003.PXCN).

Any additional documents / instructions / manuals can be printed and/or sent on request.

³ Sailsense Analytics SA/NV reserves the right to alter the characteristics of the products anytime.

NAME AND ADDRESS OF MANUFACTURER

Sailsense Analytics SA

Place Sainte Gudule 5

1000 Brussels

Belgium.

Email : support@sailsense.io