

**TECH TIP:** Maintaining the hydraulic system on your equipment will result in a longer life for all components. Using Guzzler high-quality filters, maintaining proper pressures, and servicing with the proper oils will contribute greatly to the overall life and performance of your hydraulic system.

**Tailgate Cylinder** (Fig. 1)

For half-open rear door - lowers and raises the tailgate.

| Part No. | Description                               |
|----------|---|
| 1202183A | Hydraulic cylinder - 2 required per truck |



**Hoist Cylinder** (Fig. 2)

Raises debris body for dumping

| Part No. | Description  |
|----------|--|
| 1200334A | Hoist cylinder - 3 stage for Guzzler Classic                 |
| 1200910  | Hoist cylinder - Trunnion mount for XCR                      |
| 1201676A | Hoist cylinder - Trunnion mount for DF ACE                   |
| 1201931A | Hoist cylinder - Trunnion mount for CF ACE                   |
| 1202137  | Hoist cylinder - Trunnion mount for pressure off-load system |



**Tailgate Manifold Assembly**

Controls speed and has load-holding feature that locks tailgate in the up position.

| Part No. | Description   |
|----------|---|
| 1201958D | Hydraulic manifold - controls hydraulic door locks, 6 ports (Fig.3)     |
| 1202165  | Hydraulic manifold - pressure control for full-open tailgate ACEs       |
| 1202194  | Cartridge for 1201958D - hydraulic load holding check valve (not shown) |
| 1201958A | Needle valve for 1201958D - adjusts speed of cylinder                   |



**Related Items:** See Page I-5 for selection of proper check valve or counterbalance valve.

## Hydraulic Pump

Hydraulic pump for open-center system

| Part No. | Description         |
|----------|---------------------|
| 1200419  | Hydraulic gear pump |
| 1200420  | Hydraulic gear pump |

**Related Items:** See Page I-9 for troubleshooting tips. See Section U for recommended oils, lubricants and fluids.

## Variable-Volume Pressure-Compensated Pump

Used on most ACE units and Classic XCR. For correct hydraulic pump selection, call FS Solutions with your unit's serial number.

| Part No. | Description   |
|----------|---|
| 1200743  | Hydraulic valve-volume pump - left-hand rotating spline drive |
| 1200599D | Spool, Std. "C", VDP12 Style V                                |

## Control Valve

For the hydraulic system, such as opening and closing tailgate, lowering and raising debris body, and other options.

| Part No. | Description  |
|----------|--|
| 1200599  | 3-bank Hydraulic control valve (Fig.1)                     |
| 1200599A | 3-bank Hydraulic control valve with detent                 |
| 1200327  | Dust cap - keeps material away from spool                  |
| 1200828  | Relief valve - used to adjust pressure in hydraulic system |
| 1201406  | Wiper - keeps debris off spool                             |
| 1201405  | O-ring - seals each end of spool                           |
| 1200954  | Detent kit - allows handle to be in a held position.       |
| 1200323  | Handle Kit for Valve Bank                                  |



Fig. 1

## Hydraulic Cylinders

| Part No. | Description  |
|----------|--|
| 1202215  | Cylinder - opens and closes Dezurik valve                              |
| 1201175A | Repair kit used for 1201175 - allows cylinder to be rebuilt and reused |
| 1201816  | Piston - fits 1201175  |
| 1201186  | Rod clevis - allows cylinder to be connected to any option             |
| 1202199  | Cylinder   |
| 1202208  | Cylinder - for rear NX door  |

## Hydraulic Filters

| Part No. | Description                              |
|----------|--|
| 1200303  | Suction filter                           |
| 1202167  | Spin-on 25 micron filter element         |
| 1200303A | Suction filter, old style                |
| 1200304  | Suction filter element                   |
| 1201309  | Return filter assembly                   |
| 1201310  | 10 micron filter element                 |
| 46864    | 2" (51 mm) NPT suction strainer (Fig. 3) |
| 48209A   | Filter element for 48208A                |
| 42431A   | Filter element for 48208A                |
| 42431B   | 10 micron filter element for 62643M      |
| 42431    | 10 micron filter element for 62643       |
| 42429    | Oil filter assembly (SAE#20/10MIC)       |

**TECH TIP:** As with any oil filter installation, coat the seal on the new filter prior to installing it.

## Filter Breather Assembly

| Part No. | Description |
|----------|-------------|
| 70294    | 10 micron   |

## Hydraulic Tank

| Part No. | Description                          |
|----------|--------------------------------------|
| 1375213  | 50 gallon (189.3 liters) round style |

## Boom Motor

| Part No. | Description                    |
|----------|--------------------------------|
| 1202080  | Hydraulic boom motor w/ brake  |
| 1200464  | Motor, Hydraulic rotating boom |

## Boom Cylinder

| Part No. | Description                            |
|----------|--|
| 45136C   | Telescoping boom – Extendable cylinder |
| 48440E   | Telescoping boom – Lift cylinder       |
| 1202207  | Fixed boom – Lift cylinder             |

## Hydraulic Lock Assembly

| Part No. | Description                      |
|----------|----------------------------------|
| 89423    | For full-opening tailgate system |
| 89423H   | Bolt for hydraulic lock assembly |
| 89423N   | Nut for Hydraulic lock assembly  |

## Tailgate Lock



| Part No. | Description               |
|----------|---------------------------|
| 1336149  | Tailgate over-center lock |

## Shuttle Valve

| Part No. | Description             |
|----------|-------------------------|
| 47986    | Hydraulic shuttle valve |

## Sandwich Valve

| Part No. | Description   |
|----------|---|
| 1201400  | Check valve used to keep cyclone discharge valve seated when closed |
| 1200350  | Selector valve for Guzzler equipment                                |
| 46644    | Selector valve for Vactor equipment                                 |
| 1200348  | Flow divider valve  |



## Solenoid Valve

| Part No. | Description   |
|----------|---|
| 1200341  | 12V   |
| 1201771  | Block center used in conjunction with variable volume pump                  |
| 1201780  | 12V, open-center used in conjunction with open-center system hydraulic pump |
| 1201994  | Directional valve, A-B tank   |
| 45302H   | Valve Hyd. Directional, solenoid  |
| 45302EA  | Valve, Sect, 2nd or 3rd 45302E  |
| 45302IA  | Valve, Sect, 1st on 45302I  |
| 45302D   | Valve, Std. Directional, Solenoid   |
| 45302B   | Coil, 12V, Dual Wires, for BV06   |
| 1191011  | Connector, Din Standard   |

## Subplate for Solenoid Valves

| Part No. | Description                    |
|----------|--------------------------------|
| 1200344  | Sub plate                      |
| 1200346  | Sub plate - dual               |
| 1200951  | Sub plate - 2 station parallel |
| 1202008  | Sub plate - 3 station parallel |

## Hoist Cylinder Controls

| Part No. | Description  |
|----------|--|
| 1201570  | Valve 6 port - used for boom functions and on ACE and Guzzler tail-gates |
| 1202206  | Dual valve - used for hoist cylinder with a power up or down             |

**Related Items:** See Page I-9 for troubleshooting tips.

## Vibrator

Used to loosen debris when emptying the tank.  
Should not be held down continuously.

| Part No. | Description                 |
|----------|-----------------------------|
| 1200353  | Hydraulic vibrator          |
| 1200592  | Motor, global hyd. vibrator |

**TECH TIP:** For maximum vibrator life and to lessen the possibility of damaging the vacuum tank/debris body, run the vibrator 45 seconds or less ON and 90 seconds or more OFF in order for the vibrator to cool down. Never operate the vibrator with an empty tank or unless you are emptying the debris body. Running the vibrator with the tailgate closed will cause material to pack and become more difficult to empty.

**Related Items:** See Page I-9 and I-10 for troubleshooting tips.

## Recommended Practices for Handling and Storage of Hydraulic Components

The life of the hydraulic system is directly related to cleanliness. Typically, the cleaner a system is, the longer it will last. Particle or chemical contamination. Therefore is the enemy of any hydraulic system and extra effort should be taken to avoid contamination whenever and where ever possible. The following is a list of good practices to reduce or eliminate potential contamination while storing, handling, assembling and using hydraulic system components.

### Ports & Fittings

- Port plugs should remain in components and hoses until ready to use.
- Use care in removing port plugs so that plastic does not shear off in the threads
- Use caution to ensure excess paint near the port face does not chip or fall off the unit.
- The area around the port face is a sealing surface and should be protected from dents or contamination
- Fittings being screwed into the port should be clean and lubricated.

### Assembly & Storage

- Hose and tube assemblies should be flushed and capped until used.
- Reservoirs should be pickled treated with rust protection and sealed until used. At the time of use the rust protection must be flushed out.
- Never use shop air to blow out a tube, hose or reservoir as the air supply may not be “clean” air.
- Filter caps should be kept clean
- Hydraulic assembly areas should be free of airborne contaminants.
- If components are stored in a cold environment, be sure to remove any condensation that may occur as components warm up.
- If storage is prolonged, components, may need to be rust proofed.

### Fluids

- Hydraulic fluid should be filtered to ISO 18/13 or better for initial fill.
- Water and hydraulic fluid do not mix; water is considered a foreign chemical contaminant
- Any surface in contact with hydraulic fluid must be clean and dry.
- Random sampling should be taken from hydraulic system on vehicles ready to ship to ensure cleanliness level meets ISO 18/13 or better.

### Exposed Surfaces

- Exposed cylinder rods should be handled with care to avoid scratches and dents.
- Motor and pump shafts should be kept clean and free of physical damage. Splines should be coated with anti-seize compound or grease before assembly. Tapered shafts should also be protected from physical damage to shaft and coupling ID.

## Recommended Start-up Procedure for New or Rebuilt Pump or Motor

Before installing a new or rebuilt pump or motor, back out the main relief valve until the spring tension on the adjusting screw is relaxed. This will avoid the possibility of immediate damage to the replacement unit in the event that the relief valve setting has been increased beyond the recommended operating pressure prior to removing the old unit.

Before connecting any lines to the pump or motor, fill all ports with clean oil to provide initial lubrication. This is particularly important when the unit is located above the oil reservoir.

After connecting the lines and mounting the replacement unit, operate the pump or motor for at least two minutes at zero pressure at the lowest possible RPMs. During this break-in period, the unit should run free and not develop an excessive amount of heat. If the unit operates properly, the speed and the pressure can then be increased to the normal operating settings.

Reset the main relief valve to its proper setting while the pump is running at maximum operating engine (motor) speed for the vehicle.

**ALWAYS USE AN ACCURATE GAUGE WHEN ADJUSTING THE RELIEF VALVE PRESSURE SETTING.**



| PROBLEM                        | PROBABLE CAUSE   | REMEDY   |
|--------------------------------|--|--|
| Excessive pump noise           | <p>Low oil level in the reservoir</p> <p>Air in the system</p> <p>Vacuum condition</p> <p>Oil too thick</p> <p>Cold weather</p>                    | <p>Fill reservoir to the proper level with the recommended transmission fluid. DO NOT over fill or damage may result.</p> <p>Open reservoir cap and operate hydraulic system until purged.</p> <p>“bleed” hydraulic lines at the highest point downstream of auxiliary pump and while system is under pressure.</p> <p>Check inlet (suction) line and fittings for leaks.</p> <p>Check auxiliary pump function.</p> <p>Be certain correct type of oil is used for refilling or adding to the system.</p> <p>Run hydraulic system until unit is warm to the touch and noise disappears.</p> |
| Pump overheating               | <p>Internal leakage</p> <p>Heat exchanger not functioning (if so equipped)</p> <p>Fluid level low</p> <p>Relief valve and compensator settings</p> | <p>If established that excessive internal leakage is evident, return the vehicle to maintenance shop for evaluation and repair.</p> <p>Locate trouble and repair or replace.</p> <p>Add oil to operating level.</p> <p>Set relief valve and compensator in proper sequence to match schematic</p>  |
| System not developing pressure | <p>Relief valve open (if so equipped)</p> <p>Compensator mis-adjusted</p> <p>Loss of fluid internally (slippage)</p>                               | <p>Replace one or both. Do not attempt to repair cartridges, they are factory assembled and preset.</p> <p>Return vehicle to maintenance shop for repair of hydraulic system.</p>  |
| Loss of fluid                  | <p>Ruptured hydraulic lines</p> <p>Loose fittings</p> <p>Leaking gaskets or seals in pump of circuit</p>   | <p>Check all external connections, tubing and hoses. Tighten connections, replace ruptured tube or hose.</p> <p>Observe mating sections of hydraulic for leaks. Replace seals or gaskets if possible.</p> <p>Replace seals or gaskets if possible.</p>   |
| Miscellaneous                  | <p>Sheared shaft key</p> <p>Disconnected or broken drive mechanisms</p>  | <p>Locate and repair.</p>  |

| PROBLEM                                  | PROBABLE CAUSES  | REMEDY   |
|--|--|--|
| Vibrator will not run                    | <p>Power source not connected to vibrator</p> <p>Push button or solenoid not functioning</p> <p>Vibrator not grounded properly (DC only)</p> <p>Vibrator failure</p>   | <p>Check all connections.</p> <p>Replace component.</p> <p>Remove vibrator from mount and clean any paint, heavy rust, etc. from mounting surface. Add ground strap from truck box to frame.</p> <p>If warranty is still in effect, contact factory.</p> |
| Vibrator noisy                           | <p>Vibrator mounting bolts loose</p> <p>Broken welds on mounting assembly</p> <p>Motor brushes (DC only) or bearings worn</p>  | <p>Re-torque mounting bolts.</p> <p>Repair welds.</p> <p>Repair or replace.</p>  |
| Fluid leakage (hydraulic only)           | <p>Loose fittings.</p>   | <p>Replace one or both. Do not attempt to repair cartridges, they are factory assembled and preset.</p> <p>Return vehicle to maintenance shop for repair of hydraulic system.</p>  |
| Fluid in housing (hydraulic only)        | <p>Motor seal failure.</p>   | <p>Check all connections, and replace if necessary.</p>  |
| Excessive back pressure (hydraulic only) | <p>Running equipment on return line.</p> <p>Return line too small.</p> <p>Cause drain not used.</p>  | <p>Run dedicated return line.</p> <p>Use 3/4" (19.05 mm) or larger line.</p> <p>Run 1/2" (12.7 mm) or larger line from tank to case drain.</p>   |
| Pressure spikes (hydraulic only)         | <p>Running equipment from pressure line.</p> <p>Turning on pressure with oil flow set on max.</p> <p>Running system without a pressure relief valve before vibrator, or instant start when vibrator is cold.</p> | <p>Run dedicated pressure line for vibrator with flow control valve and follow plumbing diagram.</p>   |
| Over-speeding (hydraulic only)           | <p>Running system without controlling oil flow to vibrator.</p>  | <p>Set max. oil flow to vibrator at or below max. rated G.P.M.</p>   |