



www.tally-lights.com
248-331-6793


Below is the basic rundown of how to use the Wirecast Tally application:

1. Install the program by dragging the application Tally-Lights 1.0 for Wirecast to the \Applications folder.
2. Start the Telestream Wirecast application and configure the layers with Shots as appropriate.
3. Start the Tally-Lights 1.0 for Wirecast on the computer

Tally	Assignment	Action
Tally 1:	Layer 1 Clock 1	PREVIEW
Tally 2:	Layer 2 FaceTime HD Camera Video	LIVE
Tally 3:	Not Assigned	
Tally 4:	Not Assigned	
Tally 5:	Not Assigned	
Tally 6:	Not Assigned	
Tally 7:	Not Assigned	
Tally 8:	Not Assigned	

☐ Lock Tally Selection ☐ Always On Top

4. When Telestream Wirecast is properly running, then all available shots will be loaded into the Shot Selection. Click on the 'Not Assigned' button to display the list of available shots and check the boxes for the shots to be assigned to the selected Tally Light.



5. After the Shots are assigned to Tally lights, you can Lock the selection by clicking the 'Lock Tally Selection' checkbox. The program will also allow the user to require a password to unlock the selection in the Options menu. Locking the Tally Selection prohibits any configuration settings from accidentally being changed while in a live shoot.
6. As shots are selected in Wirecast, the PROGRAM and PREVIEW indicators will light next to each tally as appropriate.

7. If you would like to test the communication with the USB Tally Controller apart from the Telestream Wirecast application, you can select 'Test Window' from the Options menu. Each button can be clicked to toggle the tally light on and off.

