



QUICK START GUIDE

1. Insert the Thumb Drive into an available USB Port on the Telecast Wirestream Computer. Navigate to the Tally Install folder on the thumb drive and double click the 'Setup.exe' file. Follow the on-screen instructions.

The default install location for the Tally Lights software is:

C:\Program Files (x86)\Tally Lights LLC\

2. Once setup is complete, remove the Thumb Drive from the USB Port and store it in a safe place for any future use.
3. Connect the USB Rackmount Tally Controller to the computer running Telecast Wirestream using the included USB Cable. Once the device is properly recognized, the green LED on the USB Rackmount Tally Controller will be illuminated.

4. Connect the Tally Lights you wish to use to the USB Rackmount Tally Controller.

NOTE: The Rackmount Tally Controller (TLC-V) is designed to be used with the Tally Lights available through Tally- Lights.com. Please use caution when connecting to any other tally products as the power requirements for other tally products may vary. Never connect the USB Rackmount Tally Controller to a Camera Control Unit (CCU) unless you have verified that either; (A) the CCU can accept voltage as you may harm the CCU, or (B) you have purchased the USB Rackmount Tally Controller specifically designed for 'contact closure' circuits (Model TLC-C). Contact Tally-Lights.com with any questions or concerns you may have.

Tally-Lights.com

support@tally-lights.com

(248) 331-6793 (9am-5pm EST)