




TOWN & COUNTRY PLASTICS


Customized For Precision

Plan View

Rebar




Sectional Side View



Sectional Front View

Ground Level



Rebar is Necessary To Prevent The Unit From Floating Out Of The Ground
Insert 2x4's Inside Unit For Structural Bracing. Secure Lids On Unit Prior To Concrete Pour
Remove 2x4's Once The Concrete Has Cured
Rebar is Required for units that are larger than 2'l x 2'w x 2'h.
Lint Filter Must Be Cleaned On A Weekly Basis
Lid(s) Must Be Screwed To The Unit At All Times Except When Cleaning The Filter