



---

## **Sound Silencer™**

### Care & Maintenance Instructions

Accumulation of dust and dirt are best removed from Sound Silencer with a soft brush attachment on a vacuum cleaner. Use vacuum attachments with at least 1" soft bristles to avoid damage to the panel. Sound Silencer panels may also be brushed off with a soft-bristle brush or blown gently with compressed air. Dirt may also be removed with a dry sponge; a damp, white cloth; or similar.

For heavy soiling and stains, a mild cleaning solution may be used as directed. Test first on a small (or hidden, if possible) area of the panel. Allow test area to dry completely and look for any discoloration.

Heavily damaged panels should be replaced.