New SureColor S-Series Stand

How to Assemble The New SureColor S-Series Printer Stand

Improved Media Feed and Simple Installation

Beginning in April 2017 the SureColor S-Series line of printers (S40600, S60600, S80600) will begin shipping with an updated printer stand. These new stands will offer an easier installation with less parts required as well as improve media feed consistency. Please refer to the instructions below for proper assembly.

Stand Assembly Steps:

Stand assembly consists of Four pieces – 2 stands and 2 support beams. All the screws needed for installation are included.

Pre-attached screws need to be loosened before inserting into bottom of stand.

Insert support beam screws into holes on inside of stand and slide down to lock into place. Use holes on outside of printer stand to tighten.

Un-screw four screws on each side of stand (8 total) and attach second support beam by lining up hook with hook hole. Once the support beam hook is inserted, screw in four screws on each side to attach support beam.

Finished Stand

EPSON®
EXCEED YOUR VISION