

# PART 1. GENERAL

- **1.1. SECTION INCLUDES** 
  - A. Structural glass stair tread system, consisting of structural extruded aluminum support brackets and laminated structural glass units, and all other items necessary for a complete assembly.

## **1.2. RELATED SECTIONS**

- A. Section 03 30 00 Cast-in-Place Concrete.
- B. Section 05 10 00 Structural Metal Framing.
- C. Section 05 51 00 Metal Stairs.
- D. Section 06 11 16 Mechanically Graded Lumber.
- E. Section 07 90 00 Joint Protection.

#### 1.3. REFERENCES

A. ASTM B 221 - Standard Specification for Aluminum and Aluminum-Alloy Extruded Bars, Rods, Wire, Shapes, and Tubes.

#### 1.4. SUBMITTALS

- A. Submit under provisions of Section 01 30 00 Administrative Requirements.
- B. Product Data: Manufacturer's data sheets on each product to be used, including:
  - 1. Preparation instructions and recommendations.
  - 2. Storage and handling requirements and recommendations.

- 3. Installation methods.
- C. Shop Drawings: Show plan, sections, details, location and spacing of anchors, and relationship to adjoining work.
- D. Selection Samples: For each finished product specified, two complete sets of color chips representing the manufacturer's full range of available colors and patterns.
- E. Verification Samples: For each finish product specified, two samples, minimum size 6 inches (150 mm) square, representing actual product, color, and patterns.

## 1.5. DELIVERY, STORAGE, AND HANDLING

- A. Store products in manufacturer's unopened packaging until ready for installation.
- B. Store materials in a dry place, off the ground, where temperature will not exceed 90 degrees F (32 degrees C).
- C. Handle material in a manner that will prevent damage to finished surfaces. Do not install scratched or damaged components.

# 1.6. PROJECT CONDITIONS

A. Maintain environmental conditions (temperature, humidity, and ventilation) within limits recommended by the manufacturer for optimum results. Do not install products under environmental conditions outside manufacturer's absolute limits.

## 1.7. WARRANTY

- A. Provide manufacturer's standard 5-year warranty.
- B. Provide 5-year installer's warranty against faulty workmanship.

# PART 2. PRODUCTS

## 2.1. MANUFACTURERS

- A. Acceptable Manufacturer: GBA Architectural Products + Services, **877-280-7700**, **sales@gbaproducts.com** / www.gbaproducts.com
- B. Substitutions: Not permitted.
- C. Requests for substitutions will be considered in accordance with provisions of Section 01 60 00 Product Requirements.

# 2.2. MATERIALS - STRUCTURAL GLASS STAIR TREAD SYSTEM

- A. Glass Tread Support Brackets: Field assembled, extruded aluminum structural support brackets, sized to fit each end of the glass tread unit.
- B. Laminated Glass Tread Units: Laminated glass 3-ply units, nominally 1.25 inches thick. Size, color, and pattern to be determined
- C. Nominal size as indicated on the Drawings.

# PART 3. EXECUTION

- 3.1. EXAMINATION
  - A. Do not begin installation until the supporting structure has been properly prepared.
  - B. If structure is the responsibility of another installer, notify the Architect of unsatisfactory preparation before proceeding.

#### 3.2. PREPARATION

- A. Clean surfaces thoroughly prior to installation.
- B. Prepare surfaces using the methods recommended by the manufacturer for achieving the best result under the project conditions.

# 3.3. INSTALLATION

- A. Install in accordance with manufacturer's instructions.
- B. Assemble stair tread system according to instructions furnished by manufacturer for supporting structural support brackets.
- C. Insert structural glass units on silicone cushions and set-in grid members.
- D. Install sealant in accordance with the sealant manufacturers printed instructions.
- E. Apply sealant between frame and adjoining construction.
- 1.

## 3.4. CLEANING

A. Clean exposed surfaces of aluminum grid with clean, soft cloth and mild hand soap using gentle rubbing action. Do not use abrasive or solvent type cleaners, detergents, or paint

GBA Architectural Products + Services 877-280-7700 / sales@gbaproducts.com GlassWalk ST Floor Panels

removers.

B. Remove labels from glass pavers and clean with soft cloth and water.

# 3.5. PROTECTION

- A. Protect installed products until completion of project.
- B. Touch-up, repair or replace damaged products before Substantial Completion.

# **END OF SECTION**