



ACT

access control TECHNOLOGY

30 SECOND PROGRAMMING GUIDE (for typical system)

1. Enter Programming Mode.

Press X button followed by the programming code.
The yellow indicator should be flashing

2. Change User 1 code.

Press 0, then 1 followed by the new user 1 code
(four digits)

3. Change Programming Code.

Press 0, then  followed by the new programming
code (four digits).

4. Set Desired Relay Active Time.

Press 2, then 0. Allow the buzzer to sound for
the desired period. Press  to stop – this period
is now programmed into the relay timer.

5. Exit Programming Mode.

Press the X button. The yellow LED should
stop flashing.
The keypad is now ready for normal use.