



Nova Operating Instructions

Once the relevant button on the entrance panel has been pressed, the Nova monitor will give an audible call tone.

The picture will appear on the monitor automatically. For audio communication press the audio speech button - this button must be pressed to speak and released to hear the visitor at the entrance panel

Once communication has been made select button to release the lock. The monitor will deactivate automatically.



Brightness control button



Aux 1: -Button for auxiliary services as required -
Release Main Entrance Door



Aux 2: -Button for auxiliary services as required -
Call Porter



Contrast control button



Button to bring monitor live and manual
sequencing of any additional entry panel or
monitor.



Door lock release button



Audio speech button- this button must be pressed
to speak and released to hear the visitor at the
entrance panel