



MAC QUICK START GUIDE

1. Insert the Thumb Drive into an available USB Port on the Telestream Wirecast Computer. Locate the mounted Tally Lights Thumb drive and double click the program 'Tally Lights 1.0 for Wirecast.dmg'.
2. Drag the application 'Tally-Lights for Wirecast' into the /Application folder (Note: you may need to enter the administrator username and password)
3. Eject the Thumb Drive and remove it from the computer. Store the thumb drive in a safe place for future use.
4. Connect the USB Tally Controller to the computer running Telestream Wirecast using the included USB Cable. Once the device is properly recognized, the green LED on the USB Tally Controller will be illuminated.
5. Connect the Tally Lights you wish to use to the USB Tally Controller.
NOTE: The Tally Controller (TLC-V) is designed to be used with the Tally Lights available through Tally-Lights.com. Please use caution when connecting to any other tally products as the power requirements for other tally products may vary. **Never connect the USB Tally Controller to a Camera Control Unit (CCU) unless you have verified that either; (A) the CCU can accept voltage as you may harm the CCU, or (B) you have purchased the USB Tally Controller specifically designed for 'contact closure' circuits (Model TLC-C).** Contact Tally-Lights.com with any questions or concerns you may have.

Tally-Lights.com

support@tally-lights.com

(248) 331-6793 (9am-5pm EST)