

HOW TO APPLY NANOCOATING

**STEP
01**

OPEN NANO BOX

includes 1 bottle



**STEP
02**

GRAB YOUR HEADSET(S)

**STEP
03**

APPLY GENEROUSLY TO FABRICS

and any surface that
touches the face



**STEP
04**

ALLOW TO FULLY DRY

ideally 24 hours

NOTE: Nano is a water-based solvent that won't damage lenses or electronics if spray hits other areas. Alcohol wipes should not be used as they compromise the nano coating.